H.C.B-A2274 CAM AND CRANKSHAFT SEAL PULLER

* Engage the adjustable hook behind the seal. * Brace the push rod against the engine head then push the handle to remove the seal. * Remove the seal easily & quickly without damage to the cam & crank shaft.

Rating: Not Rated Yet
Price:

Sales price:

Discount:

Ask a question about this product

Manufacturer: HCB Specialty Tools

Description