

H.C.B-B1560 TRUCK FRONT WHEEL AXLE BEARING PULLER TOOL (JAPANESE TRUCK)



* Feature: This tool has three accessories of bearing block, depend on different accessory, you can use on Japanese trucks. It can save your time and labor when you remove the bearing from the front shaft axle.

Rating: Not Rated Yet

Price:

Sales price:

Discount:

[Ask a question about this product](#)

Manufacturer: [HCB Specialty Tools](#)

Description



STEP 1 Put the bearing block on the front shaft axle.

STEP 2 Put the bearing block on the front shaft axle.

STEP 3 Put the bearing block on the front shaft axle.

STEP 4 Put the bearing block on the front shaft axle.

STEP 5 Put the bearing block on the front shaft axle.

STEP 6 Put the bearing block on the front shaft axle.

